

METHOD STATEMENT

8) SIT ON SKIRTING

Area is cleaned and prepared.

All walls to receive sit on skirting are marked at the height of the skirting and a line is struck between these points;

Measurements are then taken between corners to attain the position of the joints in the skirting;

The sit on skirting is then cut in dry including all internal and external mitres;

All walls are then coated with approved adhesive, as are the lengths of skirting;

The sit on skirting is then affixed to all walls

8a) Tools Required

Stanley Knife, Gluing Trowel, String line, Tape Measure, Scribers , (First Aid Boxes On Site)

RISK ASSESSMENT

Minimal, as protection provided;

Possible cut from Stanley Knife.

Signed:

Position:

Date: