

METHOD STATEMENT

Wooden Floor Installation

Measurements are made and lines are struck to attain even distribution and minimal waste of the wood planking over the floor space.

Adhesive is applied with a notched trowel.

Starting at a straight wall, timber planks are laid into wet adhesive and pressed into place. P V A adhesive is then applied to each of the timber planks, tongue and groove. The planks are then knocked together to achieve a firm joint; the last cut is then used to start the next run. This carries on across the floor space until the floor is complete. The last row of boards are then pulled into position using a shunting tool, a seal can then be applied is required.

Tools Required

Jigsaw, 110V Ext Leads, Transformer, Tape Measure, Hammer, Shunting Block, Wood Sliding Hammer, Set Square, Adhesive and a notched adhesive trowel

RISK ASSESSMENT

Minimal, as protection provided;

Signed:

Position:

Date: